



DM220-U08



Portable Photo / Video / Music Backup DVD Burner

Feature

- Directly copy from USB drive or flash card to DVD with NO PC NEEDED
- Designed to support the latest generation of high-speed and high capacity memory cards (CF High-Speed, UDMA, SDHC, & SDXC)
- USB 2.0 host for copying photo / video files directly from digital camera and camcorder without using a PC
- Files can be shared between DVD/CD, Flash memory Card, and USB storage devices
- Selectable copy modes: Copy by file type [Photo/Video/Music] are supported
- Two built-in card reader slots (CF Type I/II and Multiple Card Slot) support most major memory card formats
- Supports data burning on Double-Layer (DL) DVD discs
- Fast and reliable data back from memory cards or USB devices to DVD/CD
- Advanced professional features that include: Disc Spanning and Time Stamping
- Backlit LCD display allows function settings to be read easily
- Hi-speed USB 2.0 interface for PC connection

Copy & Share Instantly with DVD

Specifications	
Model	DM220-U08
Recording Device	Slim Type Super-multi DVD Burner
Compatible Disc Types	Blank DVD+R/RW, DVD-R/RW, DVD+R DL, CD-R/CD-RW, M-Disc™
Compatible Memory Cards	CompactFlash™, SD™ Card, microSD (via adapter), MemoryStick / Pro, xD Card
Card Slots	CF & Multiple Card Slot [SD/MS/xD]
Stand-alone Copy Method	Single-session or Multi-session, Selectable
Compatible File Systems	Standard FAT 16/32 Memory Cards & USB drives
Copy Mode by File Type	Copy All, Copy Photo, Copy Video, Copy Music, Copy Selected
File Exchangeability	DVD/CD <=> Flash Card ; DVD/CD <=> USB Storage Flash Card <=> USB Storage
LED Indicator	Green (power on / standby), Red (fail / battery low)
Display	Graphic display with white backlight for user-friendly interface
I/O Interface	Hi-speed USB 2.0 to PC or MAC as external DVD burner
USB Host	Support USB Host for external USB Mass Storage Class devices
O.S. Supported	Windows 10/8.1/8/7/XP, MAC OS 10.2X & above
AC/DC Power	100-240V(50-60Hz) universal AC adapter (DC 5V, 2A) AA x 4 rechargeable Ni-MH battery (Batteries are not included)
Dimensions	145 W x 154 L x 43.4H mm ; 5.71 W x 6.06 L x 1.71H inches
Weight	650 g or 1.3 lbs (batteries are not included)
Accessories	Power adapter, USB cable, Quick Guide, and User's Manual CD

