EZ DigiMagic™

DM220-D08E

Portable Digital Photos Backup DVD Burner

Features

- One-touch copy from a flash memory card to DVD disc
- High capacity flash card backup – Store up to 4GB of images on one DVD disc, and works with all DVD/CD recordable media
- Designed to support the latest generation of high-speed and high capacity memory cards (CF High-Speed, UDMA, SDHC, & SDXC)
- Backup with data comparison
- Advanced "Disc Spanning" supported for high capacity flash card backup
- Single button operation with NO PC NEEDED!
- LCD display for user-friendly interface and easy operation
- High-speed USB2.0 interface for PC connection
- Can be used as an external DVD Burner drive
- Slim and portable design uses AA rechargeable batteries (batteries are not included)
- Copy counter feature available
- Optional Car Power Kit - sold separately

Copy & Share Digital Photos Instantly with DVD

Specifications	
Model	DM220-D08E
Recording Device	Slim Type Super-multi DVD Drive
Compatible Disc Types	Blank DVD+R/RW, DVD-R/RW, CD-R, CD-RW Disc
Compatible Memory Cards	CompactFlash™ , SD™ Card, microSD (via adapter), MemoryStick / Pro , xD Card
Card Slots	CF & Multiple Card Slot [SD/MS/xD]
Stand-alone Copy Method	Single-session or Multi-session, Selectable
Compatible File Systems	Standard FAT 16/32 Memory Cards
Copy Mode by File Type	Copy All, Copy Photo, Copy Video, Copy Music, Copy Selected
Control Buttons	6 keys [▲, ▼, ◄, ►, Eject, Set /Copy]
LED Indicator	Green (power on / standby), Red (fail / battery low)
Display	Graphic display with white backlight for user-friendly interface
I/O Interface	Hi-speed USB 2.0 to PC or MAC as external DVD burner
O.S. Supported	Windows 10/8.1/8/7/XP, MAC OS 10.2X & above
AC/DC Power	100-240V(50-60Hz) universal AC adapter (DC 5V, 2A) AA x 4 rechargeable Ni-MH battery (Batteries are not included)
Dimensions	145 W x 154 L x 43.4H mm ; 5.71 W x 6.06 L x 1.71H inches
Weight	650 g or 1.3 lbs (batteries are not included)
Accessories	Power adapter, USB cable, Quick Guide, and User's Manual CD